


# Whirlpool GHW9100LW2 02 - DOOR AND LATCH PARTS

## DOOR AND LATCH PARTS

For Models: GHW9100LW2, GHW9100LQ2  
(White/Platinum) (White/Blue)



8180206

3

Whirlpool [Residential Whirlpool GHW9100LW2 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
5	<a href="#">8182119</a>			Bellow
6	8181663	<a href="#">8182210</a>		Clamp, Bellow
7	8181700	<a href="#">8182634</a>		Lock, Door
8	8181760	<a href="#">8540725</a>		Screw
9	<a href="#">8181651</a>			Hook, Door
10	8181758	<a href="#">8182214</a>		Screw
11	<a href="#">8181652</a>			Pin, Safety
12	<a href="#">8181653</a>			Spring
13	<a href="#">8181654</a>			Washer
14	8181664	<a href="#">8182211</a>		Clamp, Bellow To Front Panel
15	8181659	<a href="#">W10128586</a>		Clamp, Glass Support
16	<a href="#">8181650</a>			Clamp, Glass
17	<a href="#">8181785</a>			Screw
18	<a href="#">8181845</a>			Foam, Door Handle
19	<a href="#">8181847</a>			Screen, Door
20	8181848	<a href="#">8182992</a>		Door Frame Assembly

"	8181878	<a href="#">8182989</a>	Frame
21	<a href="#">8181655</a>		Glass, Door
22	8181849	<a href="#">W10322338</a>	Frame
23	<a href="#">8181843</a>		Hinge, Door
24	<a href="#">8181660</a>		Screw
25	<a href="#">8181661</a>		Screw, Actuator
26	<a href="#">8181718</a>		Tube, Dispenser To Bellow
27	<a href="#">8181842</a>		Trim, Upper Left
"	<a href="#">8181875</a>		Trim, Upper Left
28	<a href="#">8181841</a>		Cover, Hinge
"	<a href="#">8181874</a>		Cover, Hinge
29	<a href="#">8181844</a>		Cover, Hinge
"	<a href="#">8181876</a>		Cover, Hinge
30	<a href="#">8181840</a>		Trim, Lower
"	<a href="#">8181873</a>		Trim, Lower
31	<a href="#">8181846</a>		Handle, Door
"	<a href="#">8181877</a>		Handle, Door
32	<a href="#">8181929</a>		Clip, Trim
33	<a href="#">8181839</a>		Trim, Upper Right
"	<a href="#">8181872</a>		Trim, Upper Right
34	8181759	<a href="#">3400805</a>	Screw, 8-18 X 3/64

