


Whirlpool GHW9100LW2 04 - DISPENSER PARTS

DISPENSER PARTS

For Models: GHW9100LW2, GHW9100LQ2
(White/Platinum) (White/Blue)



8180206

7

Whirlpool [Residential Whirlpool GHW9100LW2 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8181694			Valve, Inlet
2	8181710			Hose, Inlet Valve To Vent Pipe
3	8181751	489503		Clamp
4	8181696	W10110225		Flowmeter
6	8181708			Hose, Flowmeter
7	8181713			Nozzle, Inlet
9	8181714	280196		Ring-O
11	8181726			Cam, Actuator
12	8181725			Lever, Water Distribution
13	8181723			Actuator
14	8181759	3400805		Screw, 8-18 X 3/64
15	8181727			Spring, Lever
16	8181724			Connection, Lever
17	8182122	280198		Dispenser
18	8181712			Nozzle, Distribution
19	8181747			Seal

20	8181887		Handle, Drawer
"	8181888		Handle, Drawer
21	8181720		Drawer, Detergent
22	8181722		Container, Detergent
23	8181729	8182665	Siphon, Bleach/Softener
24	8182131		Separator
25	8181721		Hook, Drawer
26	8182123		Led, Pcb
27	8181781		Harness, Wiring
28	8181898		Cover, Pre-Wash

