


Whirlpool GHW9150PW4 04 - DISPENSER PARTS

DISPENSER PARTS

For Model: GHW9150PW4
(White/Platinum)



W10112159

7

[Whirlpool Residential Whirlpool GHW9150PW4 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8182862			Valve, Inlet
2	8182683			Hose, Inlet Valve To Dispenser
3	8181751	489503		Clamp
7	8183010	280194		Nozzle
9	8183036	280196		Ring-O
11	8181726			Cam, Actuator
12	8181725			Lever, Water Distribution
13	8181723			Actuator
15	8181727			Spring, Lever
16	8181724			Connection, Lever
17	8183032	280198		Dispenser
18	8181712			Nozzle, Distribution
19	8181747			Seal
20	8181887			Handle, Drawer
21	8181720			Drawer, Detergent
22	8181722			Container, Detergent

23	8182665	Siphon, Bleach/Softener
24	8182131	Separator
25	8181721	Hook, Drawer
26	8182123	Led, Pcb
27	8182863	Harness, Wiring
28	8181898	Cover, Pre-Wash

