


Whirlpool GHW9160PW0 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool GHW9160PW0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182271		Not Available	Use & Care Guide
"	8182277			Tech Sheet
"	8182615		Not Available	Energy Guide
"	8182196		Not Available	Quick Start Guide
"	8182239		Not Available	Dispenser Guide
"	8182270		Not Available	DVD-Instruction
2	8181799	8181641		Top
3	8181630	8182609		Cabinet
4	8181838			Panel, Front
5	8181643			Toe Panel
6	8181636			Foot, Leveling
7	8181763			Bracket, Spring
8	8181634			Brace, Side Panel
9	8181635			Pan, Bottom
10	8182118	8182698		Panel, Rear
11	8182117	W10003040		Brace, Transport

12	8182124	W10289554A	Bolt
"	8182125	W10289554A	Bolt
13	8181706	76314	Hose, Inlet 6 Ft. Hose With Elbow
"	8181707	76314	Hose, Inlet 6 Ft. Hose With Elbow
14	8182120	8182649	Cord, Power
15	8181690	8182635	Strain Relief
16	8182607	W10138248	Brace, Rear
17	8182209		Retainer, Drain Hose
18	8181737		Hose, Drain
19	8181738		Connector, Hose Outlet
20	8181752	3367052	Clamp, Hose
22	8181683	W10326464	Filter, Interference
23	8181695		Switch, Pressure
24	8181739	W10004260	Hose, Pressure Switch
25	8181691		Screw
26	8181767	8540268	Cover, Transport
27	8181768	W10280024	U-Bend, Drain Hose
28	8181828	488729	Screw
29	8181930	W10085220	Microswitch
30	8182200	8182699	Grommet, Cord Support
31	8182201		Screw, 3 X 8 mm
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	8182109		Harness Channel

