


# Whirlpool GHW9250MQ2 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: GHW9250MW2, GHW9250MQ2, GHW9250ML2, GHW9250MT2  
 (White/Platinum) (White/Blue) (Pewter) (Biscuit)



8180305

5

Whirlpool Residential Whirlpool GHW9250MQ2 Washer Parts Parts Diagram 03 - CONTROL PANEL PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182088		Not Available	Panel, Control (Platinum)
"	<a href="#">8182089</a>			Panel, Control
"	<a href="#">8182090</a>			Panel, Control
"	<a href="#">8182091</a>			Panel, Control
2	<a href="#">8182056</a>			User Interface
3	<a href="#">8181860</a>			Button, Power
4	<a href="#">8181861</a>			Button, Start
5	<a href="#">8181863</a>			Button Set, Soil Level
"	<a href="#">8181882</a>			Button Set, Soil Level
"	<a href="#">8182052</a>			Button Set, Soil Level
"	<a href="#">8182053</a>			Button Set, Soil Level
6	<a href="#">8181862</a>			Button, Pause/Cancel
7	<a href="#">8181864</a>			Button Set, Options
"	<a href="#">8181883</a>			Button Set, Options
"	<a href="#">8182068</a>			Button Set, Options
"	<a href="#">8182069</a>			Button Set, Options

8	<a href="#">8181865</a>		Button Set, Spin/Temperature
"	<a href="#">8181884</a>		Button Set, Spin/Temperature
"	<a href="#">8182054</a>		Button Set, Spin/Temperature
"	<a href="#">8182055</a>		Button Set, Spin/Temperature
9	<a href="#">8181868</a>		Light, Indicator
10	<a href="#">8181856</a>		Window, Display
11	<a href="#">8181870</a>		Light, Indicator
12	<a href="#">8181871</a>		Light, Indicator
13	8182224	Not Available	Brace, Front Top
14	8181640	<a href="#">8182800</a>	Channel, Water
15	8182220	<a href="#">8182664</a>	Control-Elec
16	8181756	<a href="#">488729</a>	Screw
17	<a href="#">8182212</a>		Harness, Wiring
18	<a href="#">8182058</a>		Light, Indicator
19	<a href="#">8181869</a>		Light, Indicator
20	<a href="#">8181855</a>		Bezel, Knob
21	<a href="#">8181857</a>		Overlay, Door
22	8181858	<a href="#">8303811</a>	Badge, Assembly
23	<a href="#">8181859</a>		Knob, Control
"	<a href="#">8181881</a>		Knob, Control
"	<a href="#">8182050</a>		Knob, Control
"	<a href="#">8182049</a>		Knob, Control
24	<a href="#">8181852</a>		Endcap, Left
"	<a href="#">8182064</a>		Endcap, Left
"	<a href="#">8182066</a>		Endcap, Left
25	<a href="#">8181853</a>		Endcap, Right
"	<a href="#">8182065</a>		Endcap, Right
"	<a href="#">8182067</a>		Endcap, Right

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>