


Whirlpool GHW9250MT1 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Models: GHW9250MW1, GHW9250MQ1, GHW9250ML1, GHW9250MT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)



8180205

3

Whirlpool [Residential Whirlpool GHW9250MT1 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
5	8182119			Bellow
6	8181663	8182210		Clamp, Bellow
7	8181700	8182634		Lock, Door
8	8181760	8540725		Screw
9	8181651			Hook, Door
10	8181758	8182214		Screw
11	8181652			Pin, Safety
12	8181653			Spring
13	8181654			Washer
14	8181664	8182211		Clamp, Bellow To Front Panel
15	8181659	W10128586		Clamp, Glass Support
16	8181650			Clamp, Glass
17	8181785			Screw
18	8181845			Foam, Door Handle
20	8182044	8182992		Door Frame Assembly
"	8182043	8182989		Frame

"	8182086	8182990		Frame
"	8182087		Not Available	Door Frame Asm (Biscuit)
21	8181655			Glass, Door
22	8181849	W10322338		Frame
"	8181658	W10163308		Frame
23	8181843			Hinge, Door
24	8181660			Screw
25	8181661			Screw, Actuator
26	8181718			Tube, Dispenser To Bellow
27	8181842			Trim, Upper Left
"	8181875			Trim, Upper Left
"	8182078		Not Available	Trim, Upper Left (Pewter)
"	8182079			Trim, Upper Left
28	8181841			Cover, Hinge
"	8181874			Cover, Hinge
"	8182082		Not Available	Cover, Hinge (Outer) (Pewter)
"	8182083		Not Available	Cover, Hinge (Outer) (Biscuit)
29	8181844			Cover, Hinge
"	8181876			Cover, Hinge
"	8182074			Cover, Hinge
"	8182075		Not Available	Cover, Hinge (Inner) (Biscuit)
30	8181840			Trim, Lower
"	8181873			Trim, Lower
"	8182072			Trim, Lower
"	8182073		Not Available	Trim, Lower (Biscuit)
31	8181846			Handle, Door
"	8181877			Handle, Door
"	8182080			Handle, Door
"	8182081			Handle, Door
32	8181929			Clip, Trim
33	8181839			Trim, Upper Right
"	8181872			Trim, Upper Right
"	8182076			Trim, Upper Right
"	8182077			Trim, Upper Right
34	8181759	3400805		Screw, 8-18 X 3/64

