


Whirlpool GHW9300PW0 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Model: GHW9300PW0
(White/Platinum)



8180465

3

Whirlpool [Residential Whirlpool GHW9300PW0 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
5	8182119			Bellow
6	8181663	8182210		Clamp, Bellow
7	8181700	8182634		Lock, Door
8	8181760	8540725		Screw
9	8181651			Hook, Door
10	8181758	8182214		Screw
11	8181652			Pin, Safety
12	8181653			Spring
13	8181654			Washer
14	8181664	8182211		Clamp, Bellow To Front Panel
15	8181659	W10128586		Clamp, Glass Support
16	8181650			Clamp, Glass
17	8181785			Screw
20	8181848	8182992		Door Frame Assembly
21	8181655			Glass, Door
22	8181849	W10322338		Frame

23	8181843		Hinge, Door
24	8181660		Screw
25	8181661		Screw, Actuator
26	8181718		Tube, Dispenser To Bellow
27	8181842		Trim, Upper Left
28	8181841		Cover, Hinge
29	8181844		Cover, Hinge
30	8181840		Trim, Lower
31	8181846		Handle, Door
32	8181929		Clip, Trim
33	8181839		Trim, Upper Right
34	8181759	3400805	Screw, 8-18 X 3/64

Howes
the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]