


# Whirlpool GHW9300PW2 04 - DISPENSER PARTS

## DISPENSER PARTS

For Model: GHW9300PW2  
(White/Platinum)



8181271

7

Whirlpool Residential Whirlpool GHW9300PW2 Washer Parts Parts Diagram 04 - DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8181694</a>			Valve, Inlet
2	<a href="#">8182683</a>			Hose, Inlet Valve To Dispenser
3	8181751	<a href="#">489503</a>		Clamp
7	8183010	<a href="#">280194</a>		Nozzle
9	8183036	<a href="#">280196</a>		Ring-O
11	<a href="#">8181726</a>			Cam, Actuator
12	<a href="#">8181725</a>			Lever, Water Distribution
13	<a href="#">8181723</a>			Actuator
15	<a href="#">8181727</a>			Spring, Lever
16	<a href="#">8181724</a>			Connection, Lever
17	8183032	<a href="#">280198</a>		Dispenser
18	<a href="#">8181712</a>			Nozzle, Distribution
19	<a href="#">8181747</a>			Seal
20	<a href="#">8181887</a>			Handle, Drawer
21	<a href="#">8181720</a>			Drawer, Detergent
22	<a href="#">8181722</a>			Container, Detergent

23	<a href="#">8182665</a>	Siphon, Bleach/Softener
24	<a href="#">8182131</a>	Separator
25	<a href="#">8181721</a>	Hook, Drawer
26	<a href="#">8182123</a>	Led, Pcb
27	<a href="#">8182682</a>	Harness, Wiring
28	<a href="#">8181898</a>	Cover, Pre-Wash

