


Whirlpool GHW9400PT2 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: GHW9400PW2, GHW9400PL2, GHW9400PT2
(White/Platinum) (Pewter) (Biscuit)

AUTOMATIC
WASHER



7-06 Printed In U.S.A. (drd)

1

Part No. 8181272

Whirlpool Residential Whirlpool GHW9400PT2 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|---------------|-------------------|
| 1 | 8182750 | | Not Available | Use & Care Guide |
| " | 8182677 | | | Tech Sheet |
| " | 8182270 | | Not Available | DVD-Instruction |
| " | 8182658 | | | Quick Start Guide |
| 2 | 8181641 | | | Top |
| " | 8182061 | | | Top |
| " | 8181830 | | | Top |
| 3 | 8181630 | 8182609 | | Cabinet |
| " | 8182063 | | | Cabinet |
| " | 8181805 | | | Cabinet |
| 4 | 8181838 | | | Panel, Front |
| " | 8182060 | | | Panel, Front |
| " | 8182059 | | | Panel, Front |
| 5 | 8181643 | | | Toe Panel |
| " | 8182062 | | | Toe Panel |
| " | 8181809 | | | Toe Panel |

| | | | |
|----|-------------------------|----------------------------|---------------------------------|
| 6 | 8181636 | | Foot, Leveling |
| 7 | 8181763 | | Bracket, Spring |
| 8 | 8183008 | | Brace, Side Panel |
| 9 | 8181635 | | Pan, Bottom |
| 10 | 8182698 | | Panel, Rear |
| 11 | 8182661 | W10003040 | Brace, Transport |
| 12 | 8182797 | W10289554A | Bolt |
| " | 8182798 | W10289554A | Bolt |
| 13 | 8182795 | 89503 | Hose-Inlet |
| " | 8182792 | 89503 | Hose-Inlet |
| 14 | 8183009 | | Cord, Power |
| 15 | 8181690 | 8182635 | Strain Relief |
| 16 | 8182116 | W10138248 | Brace, Rear |
| 17 | 8182701 | | Clip, Outer Hose Holder |
| 18 | 8181737 | | Hose, Drain |
| 19 | 8181738 | | Connector, Hose Outlet |
| 20 | 8181752 | 3367052 | Clamp, Hose |
| 21 | 8181632 | | Brace, Top |
| 22 | 8181683 | W10326464 | Filter, Interference |
| 23 | 8181695 | | Switch, Pressure |
| 24 | 8181739 | W10004260 | Hose, Pressure Switch |
| 25 | 8181691 | | Screw |
| 26 | 8182700 | 8540268 | Cover, Transport |
| 27 | 8181768 | W10280024 | U-Bend, Drain Hose |
| 28 | 8181828 | 488729 | Screw |
| 29 | 8181930 | W10085220 | Microswitch |
| 30 | 8182699 | | Grommet, Cord Support |
| 31 | 8182201 | | Screw, 3 X 8 mm |
| 32 | 8182702 | | Clip, Outer Hose Holder |
| " | BLANK | Not Available | Following Parts Not Illustrated |
| " | 8182109 | | Harness Channel |

