


# Whirlpool GHW9460PW0 01 - TOP AND CABINET PARTS



7-05 Printed In U.S.A. (drd)

1

Part No. 8180466 Rev. A

Whirlpool [Residential Whirlpool GHW9460PW0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182276		Not Available	Use & Care Guide
"	<a href="#">8182277</a>			Tech Sheet
"	8182317		Not Available	Energy Guide
"	8182270		Not Available	DVD-Instruction
"	8182258		Not Available	Dispenser Guide
"	8182196		Not Available	Quick Start Guide
2	<a href="#">8181641</a>			Top
"	<a href="#">8182061</a>			Top
3	8181630	<a href="#">8182609</a>		Cabinet
"	<a href="#">8182063</a>			Cabinet
4	<a href="#">8181838</a>			Panel, Front
"	<a href="#">8182060</a>			Panel, Front
5	<a href="#">8181643</a>			Toe Panel
"	<a href="#">8182062</a>			Toe Panel
6	<a href="#">8181636</a>			Foot, Leveling
7	<a href="#">8181763</a>			Bracket, Spring

8	<a href="#">8181634</a>		Brace, Side Panel
9	<a href="#">8181635</a>		Pan, Bottom
10	8182118	<a href="#">8182698</a>	Panel, Rear
11	8182117	<a href="#">W10003040</a>	Brace, Transport
12	8182124	<a href="#">W10289554A</a>	Bolt
"	8182125	<a href="#">W10289554A</a>	Bolt
13	8181706	<a href="#">76314</a>	Hose, Inlet 6 Ft. Hose With Elbow
"	8181707	<a href="#">76314</a>	Hose, Inlet 6 Ft. Hose With Elbow
14	8182120	<a href="#">8182649</a>	Cord, Power
15	8181690	<a href="#">8182635</a>	Strain Relief
16	8182116	<a href="#">W10138248</a>	Brace, Rear
17	<a href="#">8182209</a>		Retainer, Drain Hose
18	<a href="#">8181737</a>		Hose, Drain
19	<a href="#">8181738</a>		Connector, Hose Outlet
20	8181752	<a href="#">3367052</a>	Clamp, Hose
21	<a href="#">8181632</a>		Brace, Top
22	8181683	<a href="#">W10326464</a>	Filter, Interference
23	<a href="#">8181695</a>		Switch, Pressure
24	8181739	<a href="#">W10004260</a>	Hose, Pressure Switch
25	<a href="#">8181691</a>		Screw
26	<a href="#">8182216</a>		Cover, Transport
27	8181768	<a href="#">W10280024</a>	U-Bend, Drain Hose
28	8181828	<a href="#">488729</a>	Screw
29	8181930	<a href="#">W10085220</a>	Microswitch
30	8182200	<a href="#">8182699</a>	Grommet, Cord Support
31	<a href="#">8182201</a>		Screw, 3 X 8 mm
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	<a href="#">8182109</a>		Harness Channel

