


# Whirlpool GHW9460PW1 04 - DISPENSER PARTS

## DISPENSER PARTS

For Models: GHW9460PW1, GHW9460PL1  
(White/Platinum) (Pewter)



8180678

7

Whirlpool Residential Whirlpool GHW9460PW1 Washer Parts Parts Diagram 04 - DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8181694</a>			Valve, Inlet
2	<a href="#">8181710</a>			Hose, Inlet Valve To Vent Pipe
3	8181751	<a href="#">489503</a>		Clamp
4	8181696	<a href="#">W10110225</a>		Flowmeter
6	<a href="#">8181708</a>			Hose, Flowmeter
7	<a href="#">8181713</a>			Nozzle, Inlet
9	8181714	<a href="#">280196</a>		Ring-O
11	<a href="#">8181726</a>			Cam, Actuator
12	<a href="#">8181725</a>			Lever, Water Distribution
13	<a href="#">8181723</a>			Actuator
15	<a href="#">8181727</a>			Spring, Lever
16	<a href="#">8181724</a>			Connection, Lever
17	8182786	<a href="#">280198</a>		Dispenser
18	<a href="#">8181712</a>			Nozzle, Distribution
19	<a href="#">8181747</a>			Seal
20	<a href="#">8181854</a>			Handle, Drawer

"	<a href="#">8182070</a>	Handle, Drawer
21	<a href="#">8181720</a>	Drawer, Detergent
22	<a href="#">8181722</a>	Container, Detergent
23	<a href="#">8182665</a>	Siphon, Bleach/Softener
24	<a href="#">8181730</a>	Separator
25	<a href="#">8181721</a>	Hook, Drawer
26	<a href="#">8182123</a>	Led, Pcb
27	<a href="#">8181781</a>	Harness, Wiring

