


Whirlpool GHW9460PW4 06 - PUMP AND MOTOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

PUMP AND MOTOR PARTS

For Models: GHW9460PW4, GHW9460PL4
(White/Platinum) (Pewter)



W10112164

11

Whirlpool [Residential Whirlpool GHW9460PW4 Washer Parts](#) Parts Diagram 06 - PUMP AND MOTOR PARTS, OPTIONAL PARTS (NOT INCLUDED)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182706			Control Unit
4	8181733	W10121657		Ball
5	8181734	696392		Hose Clamp
6	8181732			Hose, Tub To Pump
7	8181753	285655		Clamp, Hose
8	8182820			Grommet, Damper
9	8181752	3367052		Clamp, Hose
10	8182821	280187		Pump-Water
11	8182816			Grommet, Damper
13	8181736			Seal, Filter Cap
14	8183027			Cap, Filter
16	8182793			Motor, Drive
17	8183035	W10137867		Harns-Wire
18	8181761	W10128585		Bolt, Motor
19	8181755	8182209		Retainer, Drain Hose

20	8181740	W10003250	Hose, Drain-Inner
		72017	Paint, Touch-Up
"		4396174	Paint, Touch-Up
"		350938	Paint, Pressurized Spray B
"		350930	Paint, Pressurized Spray B
"		4396175	Paint, Pressurized Spray
"		799344	Paint, Touch-Up)
"	BLANK	Not Available	ACCESSORY PARTS
"		285863	Water System Parts

