


# Whirlpool GST9630PG3 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Models: GST9630PW3, GST9630PG3, GST9630PL3  
(White/Grey) (Biscuit/Gold) (Pewter)

AUTOMATIC  
WASHER



11-05 Litho in U.S.A. (drd)

1

Part No. 8180907

[Whirlpool Residential Whirlpool GST9630PG3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	8578232		Not Available	Use & Care Guide
"	3955903		Not Available	Feature Sheet
"	3957478		Not Available	Energy Guide
"	8565442		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	<a href="#">4313896</a>			Do-It-Yourself Repair Manuals
2	<a href="#">8543447</a>			Top
"	<a href="#">8543448</a>			Top
"	<a href="#">8543449</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
"	<a href="#">3954357</a>			Cabinet
"	<a href="#">3956112</a>			Cabinet

6	<a href="#">62780</a>		Clip, Top And Cabinet And Rear Panel
7	<a href="#">3976348</a>		Absorber, Sound
8	<a href="#">3351614</a>		Screw, Gearcase Cover Mounting
9	3357011	<a href="#">308685</a>	Side Trim )
10	<a href="#">9724509</a>		Bumper, Lid
11	<a href="#">8318084</a>		Switch, Lid
13	355274	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
15	8559336	<a href="#">W10225136</a>	Hinge 7 Pad Assembly
16	<a href="#">91770</a>		Hinge, Lid
18	<a href="#">8319539</a>		Bearing, Lid Hinge
19	8558401	<a href="#">W10193861</a>	Lid
"	8558402	<a href="#">W10193862</a>	Lid
"	8558400	<a href="#">3957557</a>	Lid
20	<a href="#">21097</a>		Pad, Lid Hinge
21	<a href="#">3956011</a>		Handle, Lid
"	<a href="#">3956012</a>		Handle, Lid
22	<a href="#">3956010</a>		Insert, Handle
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8
31	3956079	<a href="#">3955788</a>	Cover, Dispenser
32	<a href="#">8519517</a>		Dispenser, Bleach

