


Whirlpool GST9630PW0 01 - TOP AND CABINET PARTS



06-04 Litho in U.S.A. (drd)

1

Part No. 8180439

Whirlpool [Residential Whirlpool GST9630PW0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3956025		Not Available	Installation Instructions
"	3955869		Not Available	Use & Care Guide
"	3955903		Not Available	Feature Sheet
"	3956332		Not Available	Energy Guide
"	8542482		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	3955789			Top
"	3955790			Top
"	3957075			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet
"	3956112			Cabinet

6	62780		Clip, Top And Cabinet And Rear Panel
7	3976348		Absorber, Sound
8	3400611		Screw And Washer, Lid Switch
9	3357011	308685	Side Trim)
10	9724509		Bumper, Lid
11	8054980		Switch, Lid
12	3351614		Screw, Gearcase Cover Mounting
13	355274	W10119828	Screw, Lid Hinge Mounting
15	8055257		Hinge, Lid
16	8055256		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	8319539		Bearing, Lid Hinge
19	8558401	W10193861	Lid
"	8558402	W10193862	Lid
"	8558400	3957557	Lid
20	21097		Pad, Lid Hinge
21	3956011		Handle, Lid
"	3956012		Handle, Lid
22	3956010		Insert, Handle
28	3390631		Screw, 10-16 X 3/8
31	3956079	3955788	Cover, Dispenser
32	8519517		Dispenser, Bleach

