


Whirlpool GST9679PG3 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: GST9679PW3, GST9679PG3, GST9679PB3
(White/Grey) (Biscuit/Gold) (Black/Grey)

AUTOMATIC
WASHER



11-05 Litho in U.S.A. (drd)

1

Part No. 8180908

[Whirlpool Residential Whirlpool GST9679PG3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	8578232		Not Available	Use & Care Guide
"	3955903		Not Available	Feature Sheet
"	3957477		Not Available	Energy Guide
"	8565442		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	8543447			Top
"	8543448			Top
"	8543450			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet
"	3954788			Cabinet

6	62780		Clip, Top And Cabinet And Rear Panel
7	3976348		Absorber, Sound
8	3351614		Screw, Gearcase Cover Mounting
9	3357011	308685	Side Trim)
11	8318084		Switch, Lid
13	355274	W10119828	Screw, Lid Hinge Mounting
14	21097		Pad, Lid Hinge
15	8559336	W10225136	Hinge 7 Pad Assembly
16	91770		Hinge, Lid
18	8319539		Bearing, Lid Hinge
19	8558401	W10193861	Lid
"	8558402	W10193862	Lid
"	8558403	3957558	Lid
20	9724509		Bumper, Lid
21	3956012		Handle, Lid
"	3956011		Handle, Lid
22	3956010		Insert, Handle
28	3390631		Screw, 10-16 X 3/8
31	3956079	3955788	Cover, Dispenser
32	8519517		Dispenser, Bleach

