


Whirlpool GSW9650LW0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool GSW9650LW0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	62863	3390631		Screw, 10-16 X 3/8
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	8532053			Switch, Rotary
5	8318255	8568314		Strap, Console
6	3357978			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
9	3955501			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8528337	W10339317		Switch-WL

13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	3955728		Control, Etc
18	3979346		Valve, Water Inlet And Thermistor Assembly
19	303294	3367669	Protector, Edge
20	8318201	8318046	Clip, Capacitor
21	370451	596669	Clamp, Manifold
22	8055003		Clip, Harness And Pressure Switch
23	371503	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	8317926		Hose, Vacuum Break
26	8317940	W10358149	Drain Hose Assembly
27	8283343		Retainer, Harness
28	3976395		Restraint, Hose
29	694419		Mini-Buzzer
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3347812	8528351	Clip
35	3949180	W10168257	Switch, Rotary
36	3400064		Screw, Timer Mounting
37	661605	8572720	Capacitor, Motor Start
38	3950356		Switch, Rotary
39	3955824		Panel, Console
40	3955776		Medallion
42	8536939		Clip, Knob
43	3400073		Screw, Ground
44	8538950		Knob, Timer
45	8538955		Dial, Timer
46	8538957		Knob, Control
47	3366913	3357331	Clamp, Drain
48	3976286		Shield, Capacitor
49	388326		Screw, 8-18 X 1.25
51	8271359	279962	Endcap
52	9740848		Screw, Mixing Valve Mounting
53	3357027		Nozzle, Hose Drain
54	8317387	W10213410	Ring-Tub
55	8539874		Shield, Suds
56	3955727		Harness, Wiring
58	3366912	356138	Clamp, Hose