


**Whirlpool GSX9750PG1 10 - WATER SYSTEM PARTS, OPTIONAL PARTS
(NOT INCLUDED)**

WATER SYSTEM PARTS

For Models: GSX9750PW1, GSX9750PG1
(White/Grey) (Biscuit/Gold)



8181017

15

Whirlpool [Residential Whirlpool GSX9750PG1 Washer Parts](#) Parts Diagram 10 - WATER SYSTEM PARTS,
OPTIONAL PARTS (NOT INCLUDED)
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	285442			Water System Parts
2	285321			Water System Parts
3	370447	285655		Clamp, Hose
4	16272			Connector, Straight
5	285320			Water System Parts
6	65349	285655		Clamp, Hose
7	367031			Water System Parts
	72017			Paint, Touch-Up
"	4392899			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	4392901			Paint, Pressurized Spray
"	799344			Paint, Touch-Up)
"	4392900			Paint, Bulk)
"	N/A		Not Available	OIL

"	350572		Oil
"	N/A	Not Available	LUBRICANT
"	285208		Lubricant
"	N/A	Not Available	SEALER
"	285195		Sealer Sealer, Gasket
"	N/A	Not Available	COUPLING
"	384496		Coupling, Hose Extension Kit

