


# Whirlpool GSX9885JQ1 03 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Models: GSX9885JQ1, GSX9885JT1  
(Designer White) (Biscuit)



8179884

5

Whirlpool [Residential Whirlpool GSX9885JQ1 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3355758</a>			Cap, Agitator
2	<a href="#">358237</a>			Screw And Washer
3	3951682	<a href="#">285809</a>		Cam-Agitator
4	<a href="#">3952374</a>			Bearing, Driven Cam
5	3366877	<a href="#">80040</a>		Dog-Agitator
6	<a href="#">3951632</a>			Agitator
7	<a href="#">3951744</a>			Agitator Assembly
8	8054685	<a href="#">285832</a>		Ring-Tub
9	<a href="#">8054355</a>			Gasket, Tub Ring
10	3951984	<a href="#">W10358259</a>		Basket Assembly
11	<a href="#">21366</a>			Nut, Spanner
12	301958	<a href="#">596669</a>		Clamp, Manifold
13	<a href="#">8055061</a>			Tub
14	<a href="#">3363003</a>			Mover, Clothes
15	<a href="#">389140</a>			Tub Block, Basket Drive
16	<a href="#">383727</a>			Gasket, Centerpod

17	8054711	<a href="#">353244</a>	Hose, Pressure Switch
18	<a href="#">8526793</a>		Hose, Bleach Outlet
19	<a href="#">3951608</a>		Spacer, Thrust
20	8055271	<a href="#">8541606</a>	Absorber, Sound
21	<a href="#">3949550</a>		Washer
22	3354733	<a href="#">W10074580</a>	Cap, Barrier
23	3348855	<a href="#">W10072840</a>	Fabric Softener
24	<a href="#">8055082</a>		Shield, Splash
25	3955674	<a href="#">596669</a>	Clamp, Manifold
26	<a href="#">8055272</a>		Clip, Absorber
27	<a href="#">8055273</a>		Strap, Absorber
28	<a href="#">3351189</a>		Retainer, Push-In
29	<a href="#">8271897</a>		Balance Ring

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>