


Whirlpool GVW9959KT3 04 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: GVW9959KQ3, GVW9959KL3, GVW9959KT3
(Designer White) (Pewter) (Biscuit)



8181036

7

Whirlpool [Residential Whirlpool GVW9959KT3 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3428971	3351614		Screw, Gearcase Cover Mounting
2	3196172			Screw, 6-19 X 3/8
3	304231			Screw, 8-18 X 1/2
4	8299690			Bracket, Control
5	8541034			Control, Motor
6	8054454	353244		Hose, Pressure Switch
7	8299683		Not Available	Cap, End (L.H.) (Includes Item 13) (White)
"	8299685			Cap, End
"	8299684			Cap, End
8	8054766	W10311359		Switch-WL
9	8563809			Panel, Console
"	8563810			Panel, Console
10	8299686			Cap, End
"	8299688			Cap, End
"	8299687			Cap, End

11	8571359		Control, Machine
12	1166054	719266	Screw, 8-18 X 5/8 Indented HeX Head
13	8312709		Clip-Console
14	3957285		Harness, Wiring
15	8299987		Panel, Rear
16	693995		Screw, Hex Head
17	8533972		Screw, 10-24 X 7/16
18	8055297	Not Available	Clip, Pressure Hose

