


# Whirlpool IFR82000 02 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Model: IFR82000  
(White)



W10113922

3

Whirlpool [Residential Whirlpool IFR82000 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182338	<a href="#">489355</a>		Screw, 8 X 1/2
2	8182988		Not Available	Control Panel
4	8182576	<a href="#">280110</a>		Switch And Button Assembly
5	8182577	<a href="#">280111</a>		Switch And Button Assembly
6	<a href="#">8182522</a>			Timer And Indicator Light Assembly
7	<a href="#">8182575</a>			Button, Push
8	8182323	<a href="#">3179776</a>		Screw
9	<a href="#">8182361</a>			Spring, Knob
10	8183116		Not Available	Knob
11	8183119		Not Available	Lens, Indicator
12	8183117		Not Available	Switch, Temperature