


# Whirlpool IJ41001 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool IJ41001 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3352483</a>			Cap, Agitator
2	<a href="#">358237</a>			Screw And Washer
5	<a href="#">3360611</a>			Tub Ring And Gasket Assembly
6	<a href="#">3359586</a>			Gasket, Tub Ring
7	387868	<a href="#">3956205</a>		Balance Ring
8	387867	<a href="#">8519815</a>		Clip, Balance Ring
12	<a href="#">21366</a>			Nut, Spanner
13	8271646	<a href="#">3956207</a>		Basket And Balance Ring
14	3952746	<a href="#">285868</a>		Filter
16	<a href="#">63125</a>			Tub
17	<a href="#">389140</a>			Tub Block, Basket Drive
18	<a href="#">383727</a>			Gasket, Centerpod
19	3347780	<a href="#">353244</a>		Hose, Pressure Switch
20	<a href="#">63377</a>			Agitator
26	<a href="#">3949550</a>			Washer