


Whirlpool IJ42001 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: IJ42001
(White)



8179800

5

Whirlpool Residential Whirlpool IJ42001 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
4	63235			Agitator Assembly
5	63851	W10445870		Ring-Tub
6	3359585	3976308		Gasket, Tub Ring
12	21366			Nut, Spanner
13	3951989	W10389329		Clothes Container, Assembly
14	3952746	285868		Filter
16	63849			Strain Relief, Power Cord
17	389140			Tub Block, Basket Drive
18	383727			Gasket, Centerpod
19	3347780	353244		Hose, Pressure Switch
24	3949550			Washer