


Whirlpool IJ44001 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool IJ44001 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
3	3348752			Mover, Clothes
4	3347288			Agitator
5	63851	W10445870		Ring-Tub
6	3359585	3976308		Gasket, Tub Ring
9	3363663	285811		Cam-Agitator
10	3366877	80040		Dog-Agitator
11	3363661			Bearing, Driven Cam
12	21366			Nut, Spanner
13	3951989	W10389329		Clothes Container, Assembly
14	3952746	285868		Filter
16	63849			Strain Relief, Power Cord
17	389140			Tub Block, Basket Drive
18	383727			Gasket, Centerpod
19	3347780	353244		Hose, Pressure Switch

20	3348117	285565	Agitator
22	3350389	285587	Washer
23	3347290	W10074580	Cap, Barrier
24	3348855	W10072840	Fabric Softener
26	3949550		Washer

