


Whirlpool IJ72001 01 - TOP AND CONSOLE PARTS



10-02 Litho in U.S.A. (djc)

1

Part No. 8179760

Whirlpool [Residential Whirlpool IJ72001 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3978907		Not Available	Instructions, Installation
"	LIT8314836		Not Available	Literature Parts (Use & Care Guide)
"	LIT8528189		Not Available	Literature Parts (Label, Wiring Diagram)
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	3397692			Jumper, Wire
3	694419			Mini-Buzzer
4	8271365	279962		Endcap
5	717252			Receptacle, Terminal
6	3400859			Screw, Grounding
8	8271359	279962		Endcap
9	693995			Screw, Hex Head
10	349639			HANdle And Lint Screen Assembly

11	8283378		Cover, Lint Screen
12	3978605	W10044470	Hinge, RH
"	3978606		Hinge, Lint Lid
13	688983	487240	Screw, For Mtg. Service Capacitor
14	8274261		Do-It-Yourself Repair Manuals
15	3395683		Receptacle, Multi-Terminal
16	8271390	8521918	Top
18	8271339	3957799	Knob, Control
19	3394427		Clip-Harness
20	388326		Screw, 8-18 X 1.25
21	3976584		Timer Assembly
22	297535	17258	Bumper
24	3397269		Connector, Timer
26	3403499		Connector, 2-Position
27	3403498		Connector, 3-Position
29	3390646	W10139210	Screw, 8-18 X 5/16
30	357213		Nut, Push-In
31	8299877		Harness, Wiring
32	3395384	3395385	Switch-Pts
33	8312687	3957754	Timer Knob Assembly
34	94614		Terminal
35	8271418		Bracket, Control
36	3977841	Not Available	Panel, Control
37	3936144		Do-It-Yourself Repair Manuals
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	346764		Kit, Hold Down
"	3404351		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

