


Whirlpool IJ80002 01 - TOP AND CONSOLE PARTS



02-04 Litho in U.S.A. (djc)

1

Part No. 8180254

Whirlpool [Residential Whirlpool IJ80002 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8314836		Not Available	Literature Parts (Use & Care Guide)
"	LIT3397620		Not Available	Literature Parts (Instructions, Installation)
"	LIT8535902		Not Available	Literature Parts (Label, Energy Guide)
"	LIT8528189		Not Available	Literature Parts (Label, Wiring Diagram)
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	8274261			Do-It-Yourself Repair Manuals
3	3390646	W10139210		Screw, 8-18 X 5/16
4	8271365	279962		Endcap
5	3936144			Do-It-Yourself Repair Manuals
6	388326			Screw, 8-18 X 1.25
7	3395683			Receptacle, Multi-Terminal

8	8271359	279962	Endcap
9	3400859		Screw, Grounding
10	339392		Screen, Lint
11	8283378		Cover, Lint Screen
12	3978605	W10044470	Hinge, RH
"	3978606		Hinge, Lint Lid
13	688983	487240	Screw, For Mtg. Service Capacitor
14	297535	17258	Bumper
15	693995		Screw, Hex Head
16	8271390	8521918	Top
17	3394427		Clip-Harness
18	94614		Terminal
21	8299778		Timer, 60 Hz
28	8271341	3957804	Knob, Push-To-Start
30	357213		Nut, Push-In
31	8299868	Not Available	Harness, Wiring
32	3977456		Switch, Push-To-Start
33	8312687	3957754	Timer Knob Assembly
34	8271418		Bracket, Control
35	3977840	Not Available	Panel, Control
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	8522199		Accessory Parts
"	689790		Dry Rack
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

