


Whirlpool IJ82002 02 - TOP AND CONSOLE PARTS

TOP AND CONSOLE PARTS

For Model: IJ82002
(Designer White)



8160213

3

Whirlpool [Residential Whirlpool IJ82002 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8274261			Do-It-Yourself Repair Manuals
2	3400859			Screw, Grounding
3	693995			Screw, Hex Head
4	8271365	279962		Endcap
6	388326			Screw, 8-18 X 1.25
7	694419			Mini-Buzzer
8	8271359	279962		Endcap
10	349639			HAndle And Lint Screen Assembly
11	8283378			Cover, Lint Screen
12	3978605	W10044470		Hinge, RH
"	3978606			Hinge, Lint Lid
13	688983	487240		Screw, For Mtg. Service Capacitor
15	3395683			Receptacle, Multi-Terminal
16	8271390	8521918		Top
17	8271339	3957799		Knob, Control

18	3394427		Clip-Harness
19	3397692		Jumper, Wire
20	297535	17258	Bumper
21	8299778		Timer, 60 Hz
23	3354925		Block, Connector
24	94614		Terminal
29	3390646	W10139210	Screw, 8-18 X 5/16
30	357213		Nut, Push-In
31	8299870	Not Available	Harness, Wiring
39	3395384	3395385	Switch-Pts
48	8312687	3957754	Timer Knob Assembly
50	3936144		Do-It-Yourself Repair Manuals
53	8271418		Bracket, Control
54	3977841	Not Available	Panel, Control
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	3404351		Accessory Parts
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

