


Whirlpool IM41001 03 - AGITATOR, BASKET AND TUB PARTS



8180201

5

Whirlpool [Residential Whirlpool IM41001 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3352483			Cap, Agitator
2	358237			Screw And Washer
5	3360611			Tub Ring And Gasket Assembly
6	3359586			Gasket, Tub Ring
7	3956205			Balance Ring
8	8519815			Clip, Balance Ring
12	21366			Nut, Spanner
13	3956206	3956207		Basket And Balance Ring
16	63125			Tub
17	389140			Tub Block, Basket Drive
18	383727			Gasket, Centerpod
19	3347780	353244		Hose, Pressure Switch
20	63377			Agitator
26	3949550			Washer