


# Whirlpool IM42000 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Model: IM42000  
(White)

AUTOMATIC  
WASHER



9-03 Litho in U.S.A. (dtd)

1

Part No. 8180109

Whirlpool [Residential Whirlpool IM42000 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3361044		Not Available	Literature Parts (Installation Instructions)
"	LIT3955166		Not Available	Literature Parts (Use & Care Guide)
"	LIT3955528		Not Available	Literature Parts (Energy Guide)
"	LIT8541941		Not Available	Literature Parts (Wiring Diagram)
2	8274315		Not Available	Top (White)
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	3357011	<a href="#">308685</a>		Side Trim )
8	<a href="#">3356311</a>			Screw And Washer, Lid Switch Shield
11	3949237	<a href="#">3949247</a>		Switch-Lid
13	3351355	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting

15	<a href="#">54584</a>		Hinge, Lid
16	<a href="#">91770</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">21258</a>		Bearing, Lid Hinge
19	3361411	<a href="#">W10193874</a>	Lid
20	<a href="#">358684</a>		Strike, Lid Switch
22	<a href="#">9724509</a>		Bumper, Lid
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8
31	<a href="#">90016</a>		Clip, Pressure Switch Hose

