


# Whirlpool IM42001 01 - TOP AND CABINET PARTS



1-04 Litho in U.S.A. (dtd)

1

Part No. 8180200

Whirlpool Residential Whirlpool IM42001 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3361044		Not Available	Literature Parts (Installation Instructions)
"	LIT3955166		Not Available	Literature Parts (Use & Care Guide)
"	LIT3955536		Not Available	Literature Parts (Energy Guide)
"	LIT8541941		Not Available	Literature Parts (Wiring Diagram)
2	<a href="#">8318068</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	3357011	<a href="#">308685</a>		Side Trim )
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
11	<a href="#">8318084</a>			Switch, Lid
13	3351355	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting

15	<a href="#">8318088</a>	Hinge, Lid
16	<a href="#">54583</a>	Hinge, Lid
17	<a href="#">19119</a>	Bumper, Lid Hinge
18	<a href="#">21258</a>	Bearing, Lid Hinge
19	8542383	<a href="#">W10193857</a> Lid
22	<a href="#">9724509</a>	Bumper, Lid
28	<a href="#">3390631</a>	Screw, 10-16 X 3/8

