


Whirlpool IM43000 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: IM43000
(White)

AUTOMATIC
WASHER



9-03 Litho in U.S.A. (dtd)

1

Part No. 8180093

Whirlpool [Residential Whirlpool IM43000 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3361044		Not Available	Literature Parts (Installation Instructions)
"	LIT3955167		Not Available	Literature Parts (Use & Care Guide)
"	LIT8541944		Not Available	Literature Parts (Wiring Diagram)
"	LIT3955534		Not Available	Literature Parts (Energy Guide)
2	8271378			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3356311			Screw And Washer, Lid Switch Shield
9	3949237	3949247		Switch-Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3361411	W10193874	Lid
20	358684		Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose
32	3362952		Dispenser, Bleach

