


Whirlpool IM46000 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: IM46000
(White)

AUTOMATIC
WASHER



11-03 Litho in U.S.A. (drd)

1

Part No. 8180175

Whirlpool [Residential Whirlpool IM46000 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955917		Not Available	Literature Parts (Feature Sheet)
"	LIT3955875		Not Available	Literature Parts (Use & Care Guide)
"	LIT3956908		Not Available	Literature Parts (Energy Guide)
"	LIT8542059		Not Available	Literature Parts (Wiring Diagram)
2	8274315		Not Available	Top (White)
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3356311			Screw And Washer, Lid Switch Shield
11	3949237	3949247		Switch-Lid

13	3351355	W10119828	Screw, Lid Hinge Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3361411	W10193874	Lid
20	358684		Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose

