


**Whirlpool IP42001 10 - MISCELLANEOUS PARTS, OPTIONAL PARTS  
(NOT INCLUDED)**

**MISCELLANEOUS PARTS**

For Model: IP42001  
(White)



Whirlpool [Residential Whirlpool IP42001 Washer Parts](#) Parts Diagram 10 - MISCELLANEOUS PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3957361</a>			Miscellaneous Parts Bag
2	3976300	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	<a href="#">3359452</a>			Nut, Lock
4	389102	<a href="#">W10001130</a>		Foot, Leveling
	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	BLANK		Not Available	OIL
"	<a href="#">350572</a>			Oil
"	BLANK		Not Available	LUBRICANT
"	<a href="#">285208</a>			Lubricant
"	BLANK		Not Available	SEALER

"	<a href="#">285195</a>	Sealer Sealer, Gasket
"	BLANK	Not Available
"	<a href="#">63580</a>	ACCESSORY PARTS
"	<a href="#">367031</a>	Dispenser, Fabric Softener
"	<a href="#">285320</a>	Water System Parts
"	<a href="#">285320</a>	Water System Parts

