


# Whirlpool IP72000 01 - TOP AND CONSOLE PARTS



7-04 Litho in U.S.A. (djc)

1

Part No. 8180485

Whirlpool Residential Whirlpool IP72000 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By             | Status        | Part Description   |
|------|-------------------------|-------------------------|---------------|--|
| 1    | 8562584                 |                         | Not Available | Instructions, Installation                                     |
| "    | 8533784                 |                         | Not Available | Sheet, Cycle Feature   |
| "    | 8557472                 |                         | Not Available | Use & Care Guide   |
| "    | 8528189                 |                         | Not Available | Wiring Diagram   |
| "    | BLANK                   |                         | Not Available | Following May Be Purchased<br>DO-IT-YOURSELF REPAIR<br>MANUALS |
| "    | 677818                  |                         | Not Available | Manual, Do-It- Yourself Repair<br>(Dryer)                      |
| 2    | <a href="#">8539888</a> |                         |               | Jumper, Wire   |
| 3    | <a href="#">694419</a>  |                         |               | Mini-Buzzer  |
| 4    | 8271365                 | <a href="#">279962</a>  |               | Endcap   |
| 5    | <a href="#">717252</a>  |                         |               | Receptacle, Terminal   |
| 6    | 8533951                 | <a href="#">3400859</a> |               | Screw, Grounding   |
| 8    | 8271359                 | <a href="#">279962</a>  |               | Endcap   |
| 9    | <a href="#">693995</a>  |                         |               | Screw, Hex Head  |
| 10   | <a href="#">8558463</a> |                         |               | HANdle And Lint Screen<br>Assembly                             |

|    |                         |                           |   |
|----|-------------------------|---------------------------|---|
| 11 | <a href="#">8536939</a> |                           | Clip, Knob                              |
| 12 | 8533971                 | <a href="#">90767</a>     | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 13 | 688983                  | <a href="#">487240</a>    | Screw, For Mtg. Service Capacitor       |
| 14 | <a href="#">8274261</a> |                           | Do-It-Yourself Repair Manuals           |
| 15 | <a href="#">3395683</a> |                           | Receptacle, Multi-Terminal              |
| 16 | 8557930                 | <a href="#">8563985</a>   | Top                                     |
| 18 | 8543270                 | Not Available             | Knob, Control (3) (Grey)                |
| 19 | <a href="#">3394427</a> |                           | Clip-Harness                            |
| 20 | <a href="#">388326</a>  |                           | Screw, 8-18 X 1.25                      |
| 21 | <a href="#">3976584</a> |                           | Timer Assembly                          |
| 24 | <a href="#">3397269</a> |                           | Connector, Timer                        |
| 26 | <a href="#">3403499</a> |                           | Connector, 2-Position                   |
| 27 | <a href="#">3403498</a> |                           | Connector, 3-Position                   |
| 29 | 3390646                 | <a href="#">W10139210</a> | Screw, 8-18 X 5/16                      |
| 30 | <a href="#">357213</a>  |                           | Nut, Push-In                            |
| 31 | <a href="#">8299877</a> |                           | Harness, Wiring                         |
| 32 | <a href="#">3404233</a> |                           | Switch, Push-To-Start                   |
| 33 | 8543273                 | Not Available             | Timer Knob Assembly (Grey)              |
| 34 | <a href="#">94614</a>   |                           | Terminal                                |
| 35 | <a href="#">8271418</a> |                           | Bracket, Control                        |
| 36 | 8557464                 | Not Available             | Panel, Control                          |
| 37 | <a href="#">3936144</a> |                           | Do-It-Yourself Repair Manuals           |

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>