


Whirlpool IS44000 01 - TOP AND CABINET PARTS



6-06 Litho in U.S.A. (drd)

1

Part No. 8181413

Whirlpool [Residential Whirlpool IS44000 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10044800			Installation Instructions
"	W10096020		Not Available	Feature Sheet
"	8578236		Not Available	Use & Care Guide
"	8578911		Not Available	Wiring Diagram
2	8543451	8543447		Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting
9	3976348			Absorber, Sound
10	8566266			Dispenser, Bleach
11	8318084			Switch, Lid
12	21097			Pad, Lid Hinge

13	355274	W10119828	Screw, Lid Hinge Mounting
14	9724509		Bumper, Lid
15	8559336	W10225136	Hinge 7 Pad Assembly
16	91770		Hinge, Lid
17	8319539		Bearing, Lid Hinge
18	8580057	W10193861	Lid
19	3390631		Screw, 10-16 X 3/8

