


Whirlpool IT41000 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool IT41000 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	W10122138	W10096921		Drain Hose Assembly
9	8572976			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577846	W10339333		Switch-WL
13	3948608			Bracket, Control

14	3956162	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	8318046		Clip, Capacitor
18	3979347	3979346	Valve, Water Inlet And Thermistor Assembly
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	W10118361		Harness, Wiring
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8055003		Clip, Harness And Pressure Switch
29	8572717		Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
34	8539874		Shield, Suds
35	W10112532		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	8541669		Bucket, Drain Hose
38	8541658		Bucket, Drain Hose
39	8579082	Not Available	Panel, Console
40	8543272	Not Available	Knob, Timer
41	8544947		Dial, Timer
42	8543270	Not Available	Knob, Control (3) (Grey)
43	8536939		Clip, Knob
44	8271359	279962	Endcap
45	3347868	W10339879	Tie, Cable
46	388326		Screw, 8-18 X 1.25

