


# Whirlpool ITW4300SQ2 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Model: ITW4300SQ2  
(White)

AUTOMATIC  
WASHER



11-08 Litho in U.S.A. (drd) (psw)

1

Part No. W10239482 Rev. A

[Whirlpool Residential Whirlpool ITW4300SQ2 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10200331		Not Available	Installation Instructions (English/French)
"	W10200662		Not Available	Installation Instructions (Spanish)
"	3957879		Not Available	Feature Sheet
"	W10200842		Not Available	Use & Care Guide
"	W10165605		Not Available	Energy Guide
"	8578912		Not Available	Wiring Diagram
2	<a href="#">9724509</a>			Bumper, Lid
3	8541774	<a href="#">W10193857</a>		Lid
4	W10119872	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
5	<a href="#">8318088</a>			Hinge, Lid
6	<a href="#">54583</a>			Hinge, Lid
7	<a href="#">19119</a>			Bumper, Lid Hinge
8	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
9	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting

10	<a href="#">8318084</a>	Switch, Lid
11	<a href="#">357213</a>	Nut, Push-In
12	<a href="#">8318064</a>	Top
13	<a href="#">3362952</a>	Dispenser, Bleach
14	<a href="#">21258</a>	Bearing, Lid Hinge
15	62750	Spacer, Cabinet To Top (4)
16	<a href="#">63424</a>	Cabinet
17	<a href="#">3390631</a>	Screw, 10-16 X 3/8

