


# Whirlpool IV46001 01 - TOP AND CABINET PARTS



2-09 Litho in U.S.A. (drd) (psw)

1

Part No. W10253214 Rev. A

Whirlpool [Residential Whirlpool IV46001 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10200331		Not Available	Installation Instructions (English/French)
"	W10200662		Not Available	Installation Instructions (Spanish)
"	W10200811		Not Available	Feature Sheet
"	8578236		Not Available	Use & Care Guide
"	W10183468		Not Available	Wiring Diagram
2	<a href="#">8318064</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
8	<a href="#">3362952</a>			Dispenser, Bleach
9	<a href="#">9724509</a>			Bumper, Lid
10	<a href="#">8318084</a>			Switch, Lid

11	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
12	<a href="#">W10225135</a>		Hinge, Lid
13	<a href="#">91770</a>		Hinge, Lid
14	<a href="#">21258</a>		Bearing, Lid Hinge
15	8541774	<a href="#">W1019385Z</a>	Lid
16	<a href="#">3390631</a>		Screw, 10-16 X 3/8

