


Whirlpool IV48000 02 - CONTROLS AND REAR PANEL PARTS



W10210770

3

Whirlpool [Residential Whirlpool IV48000 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	388326			Screw, 8-18 X 1.25
2	9740848			Screw, Mixing Valve Mounting
3	8055003			Clip, Harness And Pressure Switch
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	W10175553			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577843	W10337781		Switch-WL
13	3948608			Bracket, Control
14	8578842	285800		Cord-Power

15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	3400073		Screw, Ground
18	3979347	3979346	Valve, Water Inlet And Thermistor Assembly
19	8541668		Clamp, Hose
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	8271359	279962	Endcap
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8572717		Capacitor, Motor Start
29	3347868	W10339879	Tie, Cable
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400818		Screw, Timer Mounting
34	8541669		Bucket, Drain Hose
35	8541658		Bucket, Drain Hose
36	W10196917	Not Available	Panel, Console
37	8543272	Not Available	Knob, Timer
38	8544947		Dial, Timer
39	8536939		Clip, Knob
40	8543270	Not Available	Knob, Control (3) (Grey)
41	62863	3390631	Screw, 10-16 X 3/8
42	8539874		Shield, Suds
43	W10189201		Wiring, Harness
44	W10184148		Switch, Water Temperature
45	3949187	W10168262	Switch, Rotary

