


Whirlpool KAWS750LQ3 01 - TOP AND CABINET PARTS



Whirlpool [Residential Whirlpool KAWS750LQ3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3957165		Not Available	Installation Instructions
"	3955912		Not Available	Feature Sheet
"	3955871		Not Available	Use & Care Guide
"	3957353		Not Available	Energy Guide
"	8563596		Not Available	Wiring Diagram
2	8543447			Top
"	8543448			Top
3	62750			Spacer, Cabinet To Top (4)
4	21097			Pad, Lid Hinge
5	63424			Cabinet
"	3954357			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	357213			Nut, Push-In
8	3351614			Screw, Gearcase Cover Mounting
10	3357011	308685		Side Trim)

11	8318084		Switch, Lid
13	355274	W10119828	Screw, Lid Hinge Mounting
15	8559336	W10225136	Hinge 7 Pad Assembly
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	8319539		Bearing, Lid Hinge
19	3956149	3957550	Lid
"	3956150	3957551	Lid
20	8054939		Seal, Lid
28	3390631		Screw, 10-16 X 3/8
31	8055325	3955788	Cover, Dispenser
34	8519517		Dispenser, Bleach
36	3976348		Absorber, Sound

the laundry company[®]

the laundry company[®]

the laundry company[®]