


# Whirlpool KAWS750LT4 01 - TOP AND CABINET PARTS



12-05 Litho in U.S.A. (drd)

1

Part No. 8181018

Whirlpool [Residential Whirlpool KAWS750LT4 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	3955912		Not Available	Feature Sheet
"	8578233		Not Available	Use & Care Guide
"	3957353		Not Available	Energy Guide
"	8563596		Not Available	Wiring Diagram
2	<a href="#">8543447</a>			Top
"	<a href="#">8543448</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">21097</a>			Pad, Lid Hinge
5	<a href="#">63424</a>			Cabinet
"	<a href="#">3954357</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	<a href="#">357213</a>			Nut, Push-In
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
10	3357011	<a href="#">308685</a>		Side Trim )

11	<a href="#">8318084</a>		Switch, Lid
13	355274	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
15	8559336	<a href="#">W10225136</a>	Hinge 7 Pad Assembly
16	<a href="#">54583</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">8319539</a>		Bearing, Lid Hinge
19	3956149	<a href="#">3957550</a>	Lid
"	3956150	<a href="#">3957551</a>	Lid
20	<a href="#">8054939</a>		Seal, Lid
21	<a href="#">3390631</a>		Screw, 10-16 X 3/8
22	8055325	<a href="#">3955788</a>	Cover, Dispenser
23	<a href="#">8519517</a>		Dispenser, Bleach
24	<a href="#">3976348</a>		Absorber, Sound

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>