


**Whirlpool KGHS01PWH1 06 - PEDESTAL PARTS (NOT INCLUDED),
OPTIONAL PARTS (NOT INCLUDED)**

PEDESTAL PARTS (NOT INCLUDED)

For Model: KGHS01PWH1, KGHS01PMT1
(White) (Meteorite)



10

8180489

Whirlpool Residential Whirlpool KGHS01PWH1 Dryer Parts Parts Diagram 06 - PEDESTAL PARTS (NOT INCLUDED),
OPTIONAL PARTS (NOT INCLUDED)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8537141		Not Available	Literature Parts (Installation Instructions)
"	LIT8537342		Not Available	Literature Parts (Parts List)
2	8537870	8538014		Drawer Front Assembly
"	8537871	8538015		Drawer Front Assembly
"	8537872	8538016		Drawer Front Assembly
"	8537908	8538017		Drawer Front Assembly
"	8537931	8538018		Drawer Front Assembly
3	8537883			Drawer Bin
"	8537934			Drawer Bin
4	8537875	280123		Divider
"	8537935	285974		Divider
5	8537850	8578394		Slide Assembly
6	3400111			Screw, 12-14 X 5/8
7	8537852	8563585		Leveling Foot And Nut

8	3400639	3388228	Screw, 8-18 X 1/32
9	N/A	Not Available	Cabinet (Not Serviced)
10	3400842		Screw, 8-18 X 1/2
11	8537863		Pad
12	8537853		Pan, Bottom
13	9740848		Screw, Mixing Valve Mounting
14	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
	72017		Paint, Touch-Up
"	4396603	W10202939	Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	N/A	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down
"	8541503		Kit, Stack Assembly
"	8522199		Accessory Parts
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)

