


Whirlpool KGYS750LQ1 01 - TOP AND CONSOLE PARTS



03-04 Litho in U.S.A. (djc)

1

Part No. 8180272

Whirlpool Residential Whirlpool KGYS750LQ1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8535889		Not Available	Literature Parts (Instructions, Installation)
"	LIT8535890		Not Available	Literature Parts (Sheet, Cycle Feature)
"	LIT8535887			Literature Parts
"	LIT3406667		Not Available	Literature Parts (Label, Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	3977976	280013		Panel-Control
"	3977977	280014		Panel-Control
3	3400859			Screw, Grounding
4	8274353	285858		Endcap
"	8274355	285859		Endcap
5	237446	487596		Washer
6	693995			Screw, Hex Head

7	8271418		Bracket, Control
8	3405156		Switch, Rotary
9	3390646	W10139210	Screw, 8-18 X 5/16
10	349639		HANdle And Lint Screen Assembly
11	8283378		Cover, Lint Screen
"	8283380		Cover, Lint Screen
12	3978605	W10044470	Hinge, RH
"	3978606		Hinge, Lint Lid
13	688983	487240	Screw, For Mtg. Service Capacitor
14	3936144		Do-It-Yourself Repair Manuals
15	688805		Clip, Spring Knob
16	8274386	8521923	Top
"	8274387	8521924	Top
17	694419		Mini-Buzzer
18	388326		Screw, 8-18 X 1.25
19	3395683		Receptacle, Multi-Terminal
20	3956185		Knob, Timer
"	3956186		Knob, Timer
21	3398094		Switch, Push To Start
22	8274349	285858	Endcap
"	8274351	285859	Endcap
23	3399639		Switch, Rotary Temperature
24	3401695		Wire, Jumper Buzzer
"	8283276		Wire, Jumper
25	3976570		Timer, 60 Hz
26	3394427		Clip-Harness
27	8536921		Knob, Push To Start
"	8536922		Knob, Push To Start
28	3401144		Connector
29	8536939		Clip, Knob
30	357213		Nut, Push-In
31	3347243		Block, Disconnect
32	3403499		Connector, 2-Postion
33	3403498		Connector, 3-Position
34	3399638		Switch, Temperature
35	8283289	8539893	Wire, Jumper
36	3956182		Knob, Control
"	3956183		Knob, Control
37	94614		Terminal
38	8536944		Spacer, Console
"	8536945		Spacer, Console
39	8274261		Do-It-Yourself Repair Manuals
40	8533828		Nut, 3/16
41	717252		Receptacle, Terminal
42	8299881		Harness, Wiring
46	3397269		Connector, Timer
54	297535	17258	Bumper
62	3390537	8558178	Control, Electronic
63	3391885		Connector, Edge