


Whirlpool KGYS850LE1 02 - CABINET PARTS



8180273

3

Whirlpool Residential Whirlpool KGYS850LE1 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|--------|---------------------------|
| 1 | 697776 | 4331106 | | Screw, No.10-32 X 7/16 |
| 2 | 343641 | 681414 | | Screw, 10AB X 1/2 |
| 3 | 98669 | | | Lock, Front Top |
| 4 | 8541400 | | | Bracket, Cabinet |
| 5 | 3396795 | | | Cover, Terminal Block |
| 6 | 342043 | 486146 | | Screw |
| 7 | 3396805 | 280043 | | Panel-Rear |
| 8 | 18849 | | | Pad, Top Hinge |
| 9 | 692989 | | | BRacket, Dry Rack |
| 10 | 3406107 | | | Door Switch Assembly |
| 11 | 697773 | 3395530 | | Screw |
| 12 | 691366 | | | Idler And Pulley Assembly |
| 13 | 3357011 | 308685 | | Side Trim) |
| 14 | 8541401 | W10041960 | | Spring, Door |
| 15 | 8546676 | W10041960 | | Spring, Door |
| 16 | 3392100 | 49621 | | Feet-Leveling |

| | | | |
|----|-------------------------|---------------------------|--|
| " | 279810 | | Foot-Optional |
| 18 | 8530603 | 8533643 | Cabinet |
| " | 8530606 | 3977306 | Cabinet |
| " | 8530605 | | Cabinet |
| 19 | 98234 | | Clip, U-Bend |
| 20 | 18776 | | Lock, Front Top |
| 21 | 3395197 | 279740 | Panel |
| " | 3977243 | 279890 | Panel |
| " | 3978796 | 280042 | Panel |
| 22 | 693995 | | Screw, Hex Head |
| 23 | 685203 | 279220 | Clip |
| 24 | 3389441 | | Door Catch Assembly |
| 25 | 3390731 | | Seal, Door |
| 26 | 337189 | | Clip, Hinge |
| 27 | 694091 | | Trim, Side Right Hand |
| 28 | 8066056 | | Hinge, Door |
| " | 8066057 | | Hinge, Door |
| 29 | 3394083 | | Clip, Front Panel |
| 32 | 3406839 | | Dry Rack Assembly |
| 33 | 696144 | 279570 | Latch |
| 35 | 695737 | | Door, Rear |
| 36 | 3393549 | | Door, Front |
| " | 3977241 | | Door, Front |
| " | 3403110 | | Door, Front |
| 37 | 8536933 | | Handle, Door |
| " | 8536934 | | Handle, Door |
| " | 8536935 | | Handle, Door |
| 38 | 3406129 | | Seal And Bearing Assembly |
| 40 | 344020 | 3401402 | Cord, Power |
| 41 | 3394975 | | Plug, Front Panel |
| " | 3394978 | | Plug, Front Panel |
| " | 3394979 | | Plug, Front Panel |
| 43 | 3402709 | 8564134 | Board, Sound Dampening |
| 51 | 238088 | 8066217 | Hinge, Top |
| 56 | 8066065 | 341241 | Belt |
| 57 | 348780 | | Base, Motor |
| 58 | 3400500 | | Bolt, 3405245 5/16-18 X 3/4 |
| 59 | 3394341 | W10299847 | Pulley-Motor |
| 62 | 8538262 | 279827 | Motor-Drve |
| 63 | 660658 | | Clamp, Motor Mounting 343481 685441 |
| 64 | 3404162 | | Clamp, Motor |
| 67 | 337686 | Not Available | SCREW, 8-18 X .500 |