


# Whirlpool KGYS850LT1 01 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool KGYS850LT1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8535889		Not Available	Literature Parts (Instructions, Installation)
"	LIT8535890		Not Available	Literature Parts (Sheet, Cycle Feature)
"	<a href="#">LIT8535887</a>			Literature Parts
"	LIT3979569		Not Available	Literature Parts (Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	3977978	<a href="#">280015</a>		Panel-Control
"	3977979	<a href="#">280016</a>		Panel-Control
"	3977980	<a href="#">280017</a>		Panel-Control
3	<a href="#">3400859</a>			Screw, Grounding
4	8274353	<a href="#">285858</a>		Endcap
"	8274355	<a href="#">285859</a>		Endcap
"	3954772	<a href="#">285860</a>		Baffle - Oven Top

5	237446	<a href="#">487596</a>	Washer
6	<a href="#">693995</a>		Screw, Hex Head
7	<a href="#">8271418</a>		Bracket, Control
8	<a href="#">8274261</a>		Do-It-Yourself Repair Manuals
9	3390646	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
10	<a href="#">349639</a>		HANdle And Lint Screen Assembly
11	<a href="#">8283378</a>		Cover, Lint Screen
"	<a href="#">8283380</a>		Cover, Lint Screen
"	<a href="#">3979324</a>		Cover, Lint Screen
12	3978605	<a href="#">W10044470</a>	Hinge, RH
"	<a href="#">3978606</a>		Hinge, Lint Lid
13	688983	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
14	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
15	<a href="#">688805</a>		Clip, Spring Knob
16	8274386	<a href="#">8521923</a>	Top
"	8274387	<a href="#">8521924</a>	Top
"	3978787	<a href="#">8521925</a>	Top
17	337686	Not Available	SCREW, 8-18 X .500
18	<a href="#">388326</a>		Screw, 8-18 X 1.25
19	<a href="#">3395683</a>		Receptacle, Multi-Terminal
20	<a href="#">3956185</a>		Knob, Timer
"	<a href="#">3956186</a>		Knob, Timer
"	<a href="#">3956187</a>		Knob, Timer
21	<a href="#">3398094</a>		Switch, Push To Start
22	8274349	<a href="#">285858</a>	Endcap
"	8274351	<a href="#">285859</a>	Endcap
"	3954771	<a href="#">285860</a>	Baffle - Oven Top
23	<a href="#">3399640</a>		Switch, Rotary
24	<a href="#">8283276</a>		Wire, Jumper
25	<a href="#">3976570</a>		Timer, 60 Hz
26	<a href="#">3394427</a>		Clip-Harness
27	<a href="#">8536921</a>		Knob, Push To Start
"	<a href="#">8536922</a>		Knob, Push To Start
"	<a href="#">8536923</a>		Knob, Push-To-Start
28	<a href="#">3401144</a>		Connector
29	<a href="#">3398093</a>		Buzzer, Adjustable
30	<a href="#">357213</a>		Nut, Push-In
31	<a href="#">3405156</a>		Switch, Rotary
32	<a href="#">3403499</a>		Connector, 2-Postion
33	<a href="#">3403498</a>		Connector, 3-Position
34	<a href="#">3956182</a>		Knob, Control
"	<a href="#">3956183</a>		Knob, Control
"	<a href="#">3956184</a>		Knob, Control
35	<a href="#">8283279</a>		Wire, Jumper
36	<a href="#">3347243</a>		Block, Disconnect
37	<a href="#">94614</a>		Terminal
38	<a href="#">3401668</a>		Wire, Jumper
39	<a href="#">8536944</a>		Spacer, Console
"	<a href="#">8536945</a>		Spacer, Console
"	<a href="#">8536946</a>		Spacer, Console
40	<a href="#">8533828</a>		Nut, 3/16

41	<a href="#">717252</a>		Receptacle, Terminal
42	<a href="#">8299881</a>		Harness, Wiring
43	<a href="#">3397269</a>		Connector, Timer
44	297535	<a href="#">17258</a>	Bumper
45	3390537	<a href="#">8558178</a>	Control, Electronic
46	<a href="#">3391885</a>		Connector, Edge
47	<a href="#">8536939</a>		Clip, Knob
"	N/A	Not Available	ACCESSORY PARTS
"	279948	<a href="#">4392065</a>	Kit, Dryer Repair
"	<a href="#">8522199</a>		Accessory Parts
"	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">4392899</a>		Paint, Touch-Up
"	<a href="#">72032</a>		Paint, Touch-Up
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">4392901</a>		Paint, Pressurized Spray
"	786020	Not Available	PAINT, PRESSURIZED SPRAY (12 oz.) (Black)
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )
"	<a href="#">4392900</a>		Paint, Bulk )
"	<a href="#">786032</a>		Refinishing Material

