


# Whirlpool KGYS850LT1 02 - CABINET PARTS



8180273

3

Whirlpool [Residential Whirlpool KGYS850LT1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">98669</a>			Lock, Front Top
4	<a href="#">8541400</a>			Bracket, Cabinet
5	<a href="#">3396795</a>			Cover, Terminal Block
6	342043	<a href="#">486146</a>		Screw
7	3396805	<a href="#">280043</a>		Panel-Rear
8	<a href="#">18849</a>			Pad, Top Hinge
9	<a href="#">692989</a>			BRacket, Dry Rack
10	<a href="#">3406107</a>			Door Switch Assembly
11	697773	<a href="#">3395530</a>		Screw
12	<a href="#">691366</a>			Idler And Pulley Assembly
13	3357011	<a href="#">308685</a>		Side Trim )
14	8541401	<a href="#">W10041960</a>		Spring, Door
15	8546676	<a href="#">W10041960</a>		Spring, Door
16	3392100	<a href="#">49621</a>		Feet-Leveling

"	<a href="#">279810</a>		Foot-Optional
18	8530603	<a href="#">8533643</a>	Cabinet
"	8530606	<a href="#">3977306</a>	Cabinet
"	<a href="#">8530605</a>		Cabinet
19	<a href="#">98234</a>		Clip, U-Bend
20	<a href="#">18776</a>		Lock, Front Top
21	3395197	<a href="#">279740</a>	Panel
"	3977243	<a href="#">279890</a>	Panel
"	3978796	<a href="#">280042</a>	Panel
22	<a href="#">693995</a>		Screw, Hex Head
23	685203	<a href="#">279220</a>	Clip
24	<a href="#">3389441</a>		Door Catch Assembly
25	<a href="#">3390731</a>		Seal, Door
26	<a href="#">337189</a>		Clip, Hinge
27	<a href="#">694091</a>		Trim, Side Right Hand
28	<a href="#">8066056</a>		Hinge, Door
"	<a href="#">8066057</a>		Hinge, Door
29	<a href="#">3394083</a>		Clip, Front Panel
32	<a href="#">3406839</a>		Dry Rack Assembly
33	696144	<a href="#">279570</a>	Latch
35	<a href="#">695737</a>		Door, Rear
36	<a href="#">3393549</a>		Door, Front
"	<a href="#">3977241</a>		Door, Front
"	<a href="#">3403110</a>		Door, Front
37	<a href="#">8536933</a>		Handle, Door
"	<a href="#">8536934</a>		Handle, Door
"	<a href="#">8536935</a>		Handle, Door
38	<a href="#">3406129</a>		Seal And Bearing Assembly
40	344020	<a href="#">3401402</a>	Cord, Power
41	<a href="#">3394975</a>		Plug, Front Panel
"	<a href="#">3394978</a>		Plug, Front Panel
"	<a href="#">3394979</a>		Plug, Front Panel
43	3402709	<a href="#">8564134</a>	Board, Sound Dampening
51	238088	<a href="#">8066217</a>	Hinge, Top
56	8066065	<a href="#">341241</a>	Belt
57	<a href="#">348780</a>		Base, Motor
58	<a href="#">3400500</a>		Bolt, 3405245 5/16-18 X 3/4
59	3394341	<a href="#">W10299847</a>	Pulley-Motor
62	8538262	<a href="#">279827</a>	Motor-Drve
63	<a href="#">660658</a>		Clamp, Motor Mounting 343481 685441
64	<a href="#">3404162</a>		Clamp, Motor
67	337686	Not Available	SCREW, 8-18 X .500