


Whirlpool KHGV01RSS0 01 - TOP, CONTROLS AND CABINET PARTS



Whirlpool Residential Whirlpool KHGV01RSS0 Dryer Parts Parts Diagram 01 - TOP, CONTROLS AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3957653		Not Available	Guide, Use & Care
"	3957659		Not Available	Instructions, Installation (Dryer)
"	3957668		Not Available	Tech Sheet
"	W10109961		Not Available	Instructions, Installation (Decorative Mat)
2	8182866			Top Assembly
3	8182954			Screw
4	8182833			Side Panel,
5	8182832			Insulation
6	8182831			Side Panel,
7	8182929			Screw, Phillips
8	8182941			Washer, Star
9	8182955			Locknut, Nylon
10	8182896			Panel, Control
11	8182897			Support, Stiffener
12	8182931			Screw

13	8182895		User Interface
14	8182839		Switch, Drum Rotation
17	8182824		Base Assembly
18	8182827	3359452	Nut, Lock
19	8182826	W10001130	Foot, Leveling
20	8182935		Nut, Hex
21	8182905		Mat, Decorative
23	8212510	8212510A	Cleaner
24	8182840		Control Board
25	8182841		Front, Electrical Box
26	8182928		Screw, Phillips
27	8182942		Washer, Star
28	8182828		Panel, Rear
29	8182829		Cover, Terminal
30	8182825		Outlet, Blower Housing
"	BLANK	Not Available	Following Parts Not Illustrated
"	8182890		Harness, U/I Control Board
"	8182915		Harness, Main Power
"	8182879		Harness, Main Control

