


# Whirlpool KHWS01PMT2 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Model: KHWS01PMT2  
(Meteorite)



8180304

5

Whirlpool [Residential Whirlpool KHWS01PMT2 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8182163</a>			Panel, Control
2	<a href="#">8182150</a>			User Interface
3	<a href="#">8182177</a>			Button, Power
4	8182183	<a href="#">2004333</a>		Nut
5	<a href="#">8182178</a>			Button Set, Left
6	<a href="#">8182179</a>			Button Set, Middle
7	<a href="#">8182176</a>			Button Set, Right
8	<a href="#">8182180</a>			Button Set, Start
9	<a href="#">8182166</a>			Light, Indicator
10	<a href="#">8182170</a>			Window, Display
11	<a href="#">8182168</a>			Light, Indicator
12	<a href="#">8182167</a>			Light, Indicator
13	8181639		Not Available	Brace, Front Top
14	8181640	<a href="#">8182800</a>		Channel, Water
15	8182219	<a href="#">W10137702</a>		Microcomputer, Machine Control
16	8181756	<a href="#">488729</a>		Screw

17	<a href="#">8182212</a>		Harness, Wiring
18	<a href="#">8182165</a>		Light, Indicator
19	<a href="#">8182169</a>		Light, Indicator
20	<a href="#">8182171</a>		Bezel, Knob
21	<a href="#">8182181</a>		Overlay, Door
22	8182182	<a href="#">9707516</a>	Medallion
23	8182175	<a href="#">W10163301</a>	Knob, Control
24	8182174	Not Available	Endcap, Left (Meteorite)
25	<a href="#">8182164</a>		Endcap, Right

