


Whirlpool KHWS01PMT3 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: KHWS01PMT3
(Meteorite)



8180593

5

Whirlpool [Residential Whirlpool KHWS01PMT3 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182626			Panel, Control
2	8182150			User Interface
3	8182177			Button, Power
4	8182183	2004333		Nut
5	8182178			Button Set, Left
6	8182179			Button Set, Middle
7	8182176			Button Set, Right
8	8182180			Button Set, Start
9	8182166			Light, Indicator
10	8182170			Window, Display
11	8182168			Light, Indicator
12	8182167			Light, Indicator
13	8182224		Not Available	Brace, Front Top
14	8181640	8182800		Channel, Water
15	8182219	W10137702		Microcomputer, Machine Control
16	8181756	488729		Screw

17	8182212		Harness, Wiring
18	8182165		Light, Indicator
19	8182169		Light, Indicator
20	8182171		Bezel, Knob
21	8182181		Overlay, Door
22	8182182	9707516	Medallion
23	8182175	W10163301	Knob, Control
24	8182174	Not Available	Endcap, Left (Meteorite)
25	8182164		Endcap, Right
26	8182172	Not Available	Handle, Drawer (Includes Illus. 24) (Meteorite)

the laundry company[®]

the laundry company[®]

the laundry company[®]