


Whirlpool LBR4132PQ1 01 - TOP AND CABINET PARTS



1-05 Litho in U.S.A. (drd)

1

Part No. 8180589

[Whirlpool Residential Whirlpool LBR4132PQ1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3957165		Not Available	Installation Instructions
"	3955869		Not Available	Use & Care Guide
"	3955901		Not Available	Feature Sheet
"	8546683		Not Available	Wiring Diagram
"	3957344		Not Available	Energy Guide
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	8541621			Top
4	357213			Nut, Push-In
5	63128			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting
11	8318084			Switch, Lid

13	3351355	W10119828	Screw, Lid Hinge Mounting
15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542383	W10193857	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

