


Whirlpool LCE4332PQ0 01 - TOP AND CABINET PARTS



8-04 Litho in U.S.A. (drd)

1

Part No. 8180484

Whirlpool [Residential Whirlpool LCE4332PQ0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	326035915		Not Available	Use & Care Guide
"	326035893		Not Available	Wiring Diagram & Tech Sheet Assy
2	326040947			Lid
3	326040944			Top
4	326033918			Housing, Dispenser
5	326040949			Drawer, Dispenser
6	8182293	1181135		Screw
7	326034817			Bearing, Hinge
8	326038394			Hinge, Lid
9	326035414			Screw, Lid Hinge
10	326037103			Hinge, Lid
11	326034790			Bumper
12	8182294			Screw
13	326036494			Bracket, Lid Switch
14	326033879			Switch, Lid
15	326041720			Screw

16	326040942		Cabinet
17	326033911		Handle, Cabinet
18	326033978	3935130	Pin, Wheel
19	8182295	3934148	Screw, 10-16 X 1/2
20	326033979	3934872	Caster
21	326021005	326066362	Ball
22	326000047		Strap, Snubber
23	326025313	W10322205	Suspension
24	326016638	3400094	Screw, 10-32 X 3/8

